U 0 0 R I N ш > LUXUR THE NAME OF LUXURY

Premium Korean Vinyl



Tile Dimension: 184 x 950mm x 3mm | Thickness: 3mm | Packing: 19pcs/carton (3.32 m²) KW 5121 KW 7807 KW 6551 KW 7617 KW 7806 KW 7336 KW 5446 KW 6078 KW 5445 KW 7321











KW 5121 KW 7807





KW 7806









KW 7336 KW 5445

TECHNICAL DATA - L | V | N N

-	3 mm
-	0.2 mm
-	184 mm x 950 mm
-	PU Coating
Residential Commercial Light Industry	10 years 7 years N/A
EN ISO 10582	22: Domestic moderate
-	0.03(m³⋅K)/W
EN13501-1 EN ISO 11925-2 EN ISO 9239-1	Bfl – S1 Pass Pass
EN 423 ASTM F 925	Class 0 Pass
EN ISO 105-B02 ASTM F 1515	≥6 <8
EN 660-2	Wear Group : T
-	Pass
EN 434 ASTM F 2199	≤0.25 % Pass
EN ISO 717-2	$\Delta Lw = 6 dB$
EN 1815	Voltage: 0.5kV
EN 433 ASTM F 1914	≤0.1 mm <8 %
DIN 51130	R10
ISO 16000	A+
EN 14372 CPSC-CH-C 1001-09.3	N.D Pass
ISO 4918	Pass
ISO 24342	≤0.20 mm
	- Residential Commercial Light Industry EN ISO 10582 - EN13501-1 EN ISO 11925-2 EN ISO 9239-1 EN 423 ASTM F 925 EN ISO 105-B02 ASTM F 1515 EN 660-2 - EN 434 ASTM F 2199 EN ISO 717-2 EN 1815 EN 433 ASTM F 1914 DIN 51130 ISO 16000 EN 14372 CPSC-CH-C 1001-09.3 ISO 4918











FEATURES



















CERTIFICATE















PRODUCT GUIDELINE

Preparation:

- Subfloor must be clean, dry, FLAT & free of debris.
- Plan on being present during installation to ensure that all required procedures are completed and planks with visible defects are not installed.
- Always examine your flooring for damage or defects before installation.
- Any contaminants must be removed clearly prior to the installation.

Installation:

- Determine the center of the room by measuring each end wall and marking the center of the wall.
- Chalk a line across the points and measure to determine the center point. At a right angle to the chalk line, using the center point, chalk another line out to the other walls.
- Start apply the adhesive on the first quarter of the marked space & lay out approx. 15-20 minutes after applying adhesive & proceed accordingly. Different adhesive may have different properties. Read the adhesive manufactures installationcarefully before uses.
- Keep a short distance from the wall to edge of the flooring products.
- Press the product down firmly after installation & allow 24 hours to fully cured.

After Installation & Maintenance:

- Do not fix any furniture or objects to the newly installed floor.
- Do not wash or scrub the new flooring for at least 5 days after the installation.
- Sweep regularly to remove surface grit and dust. Use a damp cloth or mop to clean up any dirt and footprints.
- All spills should be cleaned up immediately.
- Do not use polishes, waxes, harsh chemicals or abrasive cleaners on the floor as they might dull or distort the finishes.